

## 筆電專用接頭對照表

品牌	型號	筆電專用接頭編號	伏特數
Acer	TravelMate 2xx Series / 3xx Series / 5xx Series / 6xx Series / AcerNote3xx Series / AcerNote Lite 370 / Anywhere 11xx / Extensa 36x Series / 39x Series / 7xx Series / 9xx Series	11	19V
	TravelMate 420 Series / 430 Series / 650 Series / 660 Series / 800 Series / AcerNote Light 3xx Series / Aspire 13xx Series / 14xx Series / 24xx Series / 29xx Series / 30xx Series / 45xx Series / 49xx Series / 50xx Series / 51xx Series / 52xx Series / 56xx Series / 59xx Series / 70xx Series / 90xx Series / 91xx Series / 94xx Series / 95xx Series / 98xx Series	5	19V
	Aspire 12xx Series / 16xx Series / 30xx Series / 35xx Series / 36xx Series / 50xx Series / TravelMate 23xx Series / 24xx Series / 32xx Series / 40xx Series / 43xx Series / 45xx Series / 47xx Series / 62xx Series / 64xx Series / 8000 / 200 Series / 300 Series / 500 Series / 600-663 Series / 720-740 Series / 800 Series / Acer Aspire 1680 / 3000 / 3500 / 3600 / 3680 / 4520 / 4530 / 4730 / 5000 / 5050 / 5100 / 5315 / 5335 / 5515 5520 / 5530 / 5530z / 5535 / 5535z / 5570 / 5570z / 5580 / 5580z / 5720 / 5730 / 5730z / 5735 / 6530 / 6920 / 6930 / 6935 / 7100 / zg5 / 8172 / 6235 / 6253 / 6292 / 8331 / 8371 / 8471 / 5720 / 5740 / 8372TG / 8472G / 8572G	5	19V
	K386S / M201T / V386SL / V386SL-25 / V486S	7	19V
	Acer Aspire 3820TG / 1200 / 1450 / 1600 / 1650 / 2420 / 2430 / 3030 / 3200 / 3510 / 3670 / 3820TG / 3935 / 4230 / 4235 / 4240 / 4310 / 4315 / 4320 / 4330 / 4332 / 4336 / 4410T / 4715Z / 4732Z / 4741G / 4745G / 5220 / 5230 / 5235 / 5236 / 5241 / 5242 / 5310 / 5315 / 5320 / 5330 / 5332 / 5335 / 5338 / 5410 / 5510 / 5515 / 5516 / 5517 / 5532 / 5534 / 5535 / 7220 / 7230 / 7330 / 5732ZG / 4810T / 4810TG / 4810TZG / 1420P / 1825PTZ / 3935 / 4730Z / 4937G / 4736Z / 4736G / 4736ZG / 5810TG / 5810TZG / 5735Z / 5738G / 5738DG / 5738Z / 5738ZG / 4730ZG / 4930G / 4935G / 5739G / 5741G / 5935G / 6930G / 6935G / 4553 / 5553 / 5745G / 5942G / 8930G / 8920G / 5943G / 8935G / 8940G / 8942G / 8943G / Extensa - EX4120 / EX4130 / EX4210 / EX4220 / EX4230Z / EX4420 / EX4610 / EX4620 / EX4620Z / EX4630 / EX4630G / EX4630Z / EX4630ZG / EX5010 / EX5120 / EX5130 / EX5210 / EX5220 / EX5230 / EX5330 / EX5410 / EX5420 / EX5420G / EX5430 / EX5430G / EX5610 / EX5610G / EX5620 / EX5620G / EX5620Z / EX5630 / EX5630G / EX5630Z / EX5630ZG / EX5725 / EX5725G / EX5730 / EX5730G / EX7630 / EX7630G / Ferrari - FR1004WTMi / FR1100 / TravelMate - 2460 / 2470 / 3020 / 3030 / 3040 / 320 / 3220 / 3230 / 3300 / 360 / 380 / 4050 / 4080 / 4320 / 4335 / 4520 / 4600 / 4720 / 5230 / 530 / 5310 / 5320 / 5510 / 5530 / 5630Z / 5670 / 5730 / 6231 / 6291 / 6293 / 7220 / 7230 / 7364 / 7520 / 7530 / A550, Aspire - 1300 / 1410 / 1640 / 1680 / 1690 / 200 / 2010 / 2020 / 2920 / 2920 / 2930 / 3000 / 3050 / 3410 / 350 / 3600 / 3610 / 3620 / 3630 / 3650 / 3660 / 3680 / 3810 / 3811 / 4220 / 4370 / 4520 / 4530 / 4535 / 4540 / 4710 / 4720 / 4730 / 4735 / 4736 / 4740 / 4810 / 4820 / 4920 / 4925 / 4930 / 4935 / 4937 / 5000 / 5050 / 5100 / 5500 / 5520 / 5530 / 5536 / 5538 / 5541 / 5542 / 5570 / 5580 / 5710 / 5715 / 5730 / 5735 / 5930 / 6530 / 6920 / 6930 / 6935 / 7100 / 7520 / 7530 / 7730 / 3810T / 3810TZG / 6493 / eMachines - eM-D / E / G, Gateway - EC Laptop - EC38 / EC54 / EC58 / ID58 / TravelMate - 210 / 220 / 230 / 2300 / 2310 / 2350 / 2400 / 2430 / 2440 / 2450 / 2480 / 260 / 280 / 290 / 3000 / 3010 / 310 / 3200 / 3210 / 3250 / 3260 / 3270 / 330 / 340 / 350 / 350 / 4000 / 4010 / 4020 / 4060 / 4070 / 4100 / 4150 / 4220 / 4500 / 4650 / 473 / 5100 / 520 / 5520 / 5600 / 5710 / 572 / 600 / 6000 / 610 / 620 / 630 / 6492 / 650 / 6592 / 660 / 720 / 730 / 740 / 800 / 8000 / 8100 / C100 / C110 / C200 / C210 / C300 / C310 / WinBook - XL / XL2 / XL3 / Xli / Aspire TimeLinX 1830T / 4820TG / 5820TG	7	19V
	Aspire 20xx Series / Aspire One A100 Series / AOA Series/ D150 / D250 Series / 751H / 531 / 531H	7	19V
	Aspire 5810TZG	8	19V
	B80A / F6F / F81 / N10JB / N51 / N81 Series / X51 / U6V Bamboo / F6VE / F80L / F81SE / N51VF / N81VG / G71GX / G73JH / F6VE / F9E / F9F / F9J / N82JQ / N82JV	4	16V
	A3 Series / A5 Series / A6 Series / A8 Series / A9 Series / X50 Series / X80 Series / M2 Series / M3 Series / M9 Series / F3 Series / F5 Series / F6 Series / F8 Series / F9 Series / Eee Top LAMBORGHINI / Eee Box / N10 Series / W5 Series / W6 Series / W7 Series / R1 Series / S6 Series / S7 Series / U1 Series / U2 Series / U5 Series / U6 Series Z35 / Z84 / K40 Series / F50 Series / F70 Series / K50 Series / M50 Series / A9 / U80 / U80V / U81A / UL80V / K611C / M51 Series / A42JC / A42JK / A42JR / A42JV / A52JK / A52JC / A52JR / F3JA / F3JC / F3JP / F3JR / F3M / F3SC / F3SV / F3TC / F5R / F5SL / F6E / F6S / F6V / F83VF / F8SA / F85G / F85P / F85R / F85V / F8VA / K40AB / K40IP / ASUS M70 Series / N50 Series / N5 Series / N70 Series / N80 Series / N8 Series / N90Sv Series / X71 Series/V2JE / K40IP / K40IJ / K40IL / K40IN / K40AD / K40AF / K40ID / K40IE / K42JB / K42JV / K50C / K50AB / K50J / K50IL / K50IN / K50IP / K50AD / K50AF / K50ID / K50IE / K51AE / N20A / N50VN / N51VN / N80VC / N81VP / X61SL / B50A / G51J 3D / G51JX / G51JX 3D / G60J / G70S / G71V / G72GX / VX1 / VX2 / VX2S / VX3 / VX5 / S6F / U2E / U6V / U33JC / F9S / N10E / N10J / N10JC / S6FM / U20A / U30JC / U35JC / U3S / U43JC / U45JC / U50VG / U53JC / U6V / U6S / U6SG / U6E / U6VC / UL20A / UL30JT / UL30VT / UL30A / UL50A / UL50VG / UL50VT / UL80JT / UL80VT / UL80VS / UX30 / UX50V / W7J / W7S / M50SA / M50SV / M50VM / M51SR / M51SN / M51VA / M51VR / M70SA / M70VM / N53JN / N61JA / N61JQ / N61JV / N61VN	5	19V
	Eee PC 700 Series / 701 / 701SD / 701SDX / 900 / 2G Surf Series / 4G Series / 4G Surf / 8G Series	20	9.5V
80G / S101H / T91 / T101MT / R2 / R2E / R2H / R2HV / PC901 / S101 / 12G / 20G / EeePC 700 Series / 901 / 904 / 1000 Series	17	12V	
Eee PC 1005HA Series / 1008HA Series / 1101HA Series / 1104HA Series / 1106HA Series	29	19	
Apple	iBook G3 / G4 / G5 / PowerBook G3 / G4 / G5	14	24V
	MacBook Air	30 (選購)	14.5V
	MacBook / MacBook Pro 13 "	31 (選購)	16.5V
	MacBook Pro 15 " / MacBook Pro 17 "	32 (選購)	18.5V
BenQ	A33 / A52 / R23E / S31 / S32 / S61 / T31 / S32W / R42 / S32 / R55U / 2000 / 2100 / A32 / A33 / A33E / A51E / R23 / R31 / S61 / Joybook A52 / A52-T25 / C42 / C42-101 / S31 / S31-C02 / S73G / S73G-C27 / S41	5	19V
DELL	Inspiron 1100 / 2000 Series / 3000 Series / 4000 Series / 5000 Series / 7500 / 8000 Series / C Dock / C Port / B120 / B130 / Latitude X200 / C400 / C500 / C600 / C800 Series / CP Series / CS Series / 110L / Inspiron 1000 / 1200 / 1300 / 2200 / 3000 / 3200 / 3500 / 7000	5	19V
	Inspiron 1100 / 2000 Series / 3000 Series / 4000 Series / 5000 Series / 7500 / 8000 Series / Latitude CP Series / CS Series / C400 / C500 Series / C600 Series / C800 Series / Precision M40 / M50	6	20V
	Inspiron Mini 10 / 12	8	19V
	Inspiron 14 / Studio XPS 13 / 15 / Vostro 1320	9	19.5V
	M6500	2	19.5V
Fujitsu	Amilo A Series / Amilo M Series / Amilo Pro V1000 / V2000 / LifeBook C1000 Series / C2000 Series / E7000 Series / S7000 Series / T4000 Series / T1010 / T2010 / U1010 / U2010 / V1010 / AH550 / P770 / MH330 / MH380 / LH530 / LH700 / M2010 / P8110 / SH560 / SH760 / T4310 / T900 / TH700 / UH900 / S6520 / S6420 / T5010	5	19V
	Solo 1000 Series / 2000 Series / 5000 Series / 9000 Series	5	19V
	BIBLO NX90M/W / FMV-BIBLO / NX90MN/W / FMV-BIBLO NX90R/W / FMV-BIBLO RS / FMV / Lifebook / Lifebook C / Lifebook E / Lifebook N / Lifebook S / Lifebook T Series	5	19V
	Amiii K7000 Series / Si1520 / LifeBook 200 Series / 3000 Series / 400 Series / 500 Series / 600 Series / 700 Series / 900 Series / A Series / B3000 Series / B5000 Series / B6000 Series / C20 Series / C300 Series / C400 Series / C5000 Series / C7000 Series / E3000 Series / E5000 Series / E6000 Series / P1000 Series / P2000 Series / P5000 Series / P7000 Series / S2000 Series / S4000 Series / S5000 Series / S6000 Series / S7000 Series / T3000 Series / T4000 Series / Sylistic 1000 / 1200 / 2300 / 3400 / 3500 / 500 / T2020 / P8010 / P1630	1	16V
LifeBook A4170 / A4177 / A4187 / A4190 / FutureTech 6200D	2	19V	

HP Compaq	Pavilion N3000 – N5000 Series / ZE1000 Series / XT Series / ZT Series / DE Series / Business Notebook nx9000 Series / DE900 Series / DG100 Series / DG200 Series / DG600 Series / DG800 Series / DG900 Series / DJ100 Series / DK400 Series / DK700 Series / ZE4000 – ZE5700 Series / Omnibook 2000 Series / 6000 Series / 7000 Series / XE Series / XT1000 Series / XT6200 Series / VT6200 Series / XE4500 Series / XT1500 Series / XT6050 Series / XT6200 Series / XF255 Series / XF335 Series / XT412 Series / XZ200 Series / XZ300 Series / ZE4000 Series / NC4000 Series / 6000 Series / 8000 Series / Presario Z100 Series	5	19V
	Business Notebook nc6300 Series / nc8430 Series / 8440 Series / 9440 Series / 7400 Series / 8420 Series / 9420 Series / Envoy 14-1011TX / 14-1012TX / Pavilion DV2-1000 / DV3-2100 / DV3100 / DV3500 / DV3-2200 / DV3-2000 / DV3000 / DV3700 / DV4-1500 / DV4-1400 / DV4-1000 / DV5-1000 / DV6-1200 / DV6-1300 / DV6-2000 / DV8-1000	10	19V
	Nc8200 Series / Evo dv Series / 6280S / 6520	8	19V
	Thin Client NC 2000 / 4000 / 6000 / 8000 Series · NX4000 / 6000 / 7000 Series / Presario CQ 20 / 35 / 40 / 41 / 45 / 60 / 61 Series TouchSmart TX2-1301AU / TX2-1324AU / TX2-1003AU / TX2-1021AU / TX2-1111AU / Presario CQ36-113TX / CQ41-222TX / CQ42-194TX / CQ42-201AX / CQ42-202AX / CQ42-225AX / CQ42-272TX / CQ42-273TX / CQ42-274TA / CQ42-290TX / CQ61-408TX / CQ61-411TX / CQ62-101TX / CQ62-203AX / CQ62-204AX / CQ62-212AX / CQ62-264TX / CQ62-271TX	10	19V
	nx8220 / nc8230 / nw8240 / Evo N1000 / N610 Series / Pavilion dv6000 / dv6100 / dv8000 / dv9000 / dv9100 / dv9200 / dv9300 / 6820s / 6520s / B1900 / B1921 / B1923 / B1924 / B1930 / B1950 / B1980	8	19V
	Presario 2500 Series / DC700 Series / Business Notebook n1050v Series / nx9000 Series / nx9005 Series / nx9010 Series / Pavilion ZE4000 – ZE5700 Series	4	16V
	NVO N100 Series / N1000 Series / DV1000 Series / DV4000 Series / DV5000 Series / DV6000 Series / DV8000 Series / ZE4900 Series / ZE2000 Series / ZT3000 Series / ZT4900 Series / Presario 900 Series / 1500 Series / 2800 Series / Evo Series / Prosignia Series / 2700 / 6820S / NW8200 / TC1000 / DM1 / DM3 / Mini311 Series / Mini 110-1011TU / 110-1038TU / 110-1040TU / 210-1035TU / 210-1039TU / 210-1040TU / 210-1043TU	8	18.5V
	mini 1000 Series / TX2000	18	19V
	Pavilion TX2500 / DV3600 / DM1-1100 / DV3-2300TX / DV3-4026TX / DV3-4038TX / DV3-4039TX / DV4-1016TX / DV4-1017TX / DV6-2166TX / DV6-3001TX / DV6-3012TX / DV6-3013TX / DV6-2167TX / DV7-4000 / Presario CQ40-740TU / CQ42-117TU / CQ42-131TU / CQ42-132TU / CQ42-219TU / CQ42-275TU / CQ62-218TU	10	18.5V
	DV3509TX	9	19.5V
IBM Lenovo	X41 Series / R30 / R31 / R32 / R40 / R40E	4	16V
	G450A / U160 / U350 /	5	19V
	T60 / X60 / R60 / Z60 Series / 3000 / C100 / N100 / V100 / S50 / R61 / R51 / R52 / ThinkPad Edge 14 / R400 / SL410 / T410 / T400S / T410S / W700 / X100E / X200 / X201 / X201S / X201T / Y560 / Z360	15	20V
	T60 Series / X60 Series / Z60 Series / R60 Series / 3000 Series	15	20V
	U350 / U450 / U450p / U550 / U550p / IdeaPadS Series S10-3T / S10-3 / S10-3S	19	20V
MSI	Wind U90 Series / U100 Series / U120 Series / U120 Series / U115 Hybrid Series / U130 / U160 / U230 / Wind12 U200 / X-Slim X320 / X340 / X400 / X410 / X600	19	20V
	Wind U150	5	19V
NEC	VersaNote Ready 220T / 230T / 330T / 340T / 360T / 433T / 440T / UltraLite II / III / SL-20 · Versa 2400 Series / 2500 Series / 5000 Series / NEC Ready 220T / 330T / 340T / 360T / 440T / NEC Versa 550 / E2000, E6000 / M320 / NEC Versa 2400 / 2500 Series	5	18.5V
	Versa 2400 Series / 2500 Series / 5000 Series	9	19.5V
	Versa 4000 / 4200 / 4230	16	12V
Panasonic	CF Series / Raven-RNE-3SX / ToughBook 25 / M31 / P1 / V25	1	16V
	CF-29 CF-50 CF-51 CF-73	4	16V
SONY	VPC-CW Series / W Series · VGN-Z Series / SR Series / FW Series / CS Series / FS Series / FJ Series / SZ Series / FS Series · PCG-FR Series / GRS Series / FRX Series / NV Series / VPCEA16FW / VPCE / A17FW / VPCEB15FW / VPCEB25FW / VPCEB27FW / VPCF116FW / VPCF115FW / VPCM125AW / VPCS116FW / VPCS117FW / VPCS125FW / VPCW115XW / VPCW126AW / VPCZ117GW / VPCZ126GW / VPCZ129GW /	2	19.5V
	VGN-TT Series / B1 Series / G1 Series / S2 Series / T1 Series / S1 Series / S2 Series / S3 Series / S5 Series / S6 Series / T Series / TX Series / TZ Series / U Series / UX Series / Y79P Series / Y90PSY Series / Z1 Series · PCG-505 Series / R505 Series / Z505 Series / 1A1N Series / 1G1N Series / 5 Series / 6 Series / 7 Series / 8 Series / 181 Series / 384 Series / 3XXX Series / 4XXX Series / 5XXX Series / 6XXX Series / 700 Series / 800 Series / B Series / C1 Series / CR Series / F Series / FX Series / G Series / GR Series / SR Series / SRX Series / TR Series / TR1 Series / U Series / VX Series / V505 Series / XR Series / XG Series / X505 Series / Z1 Series	1	16V
	Viao X Series / P Series VPCP115KW / X Series VPCX115LW / VPCX115LW / VPCX118LW / VPCX125LW / VPCX128LW / VPCX135LW	21	10.5V
TOSHIBA	Satellite A130ST1312 / 1600 Series / 1715XDS Series / 3000 Series / A65 Series / A70 Series / A75 Series / A80 Series / A100 Series / A135 Series / A200 Series / P30 Series / P35 Series / Pro L100 Series / Pro M50 Series / Pro M70 Series / Portege M600 / Dynabook AW Series / AX Series / AX2 Series / Tecra A7Series / Equipment A100-549 Series / L100 Series / M70 Series	2	19.5V
	Satellite A80 Series / A110 Series / L10 Series / L15 Series / L20 Series / L25 Series / M30X Series / M35X Series / M40 Series / M45 Series / M55 Series / M105 Series / M800 / A660 / L500 / L510 / L630 / L640 / L650 / A300 / M300 / Satellite M500 / R700	5	19V
	Qosmio E15 / F25 / Satellite 105-54000 Series / M100-ST5111 Series / P105-S6021 Series / Tecra A6 Series / A5 Series / A8 Series / Portege M500 / R600 / A600 / M900 / T210 / T230 / Satellite Pro 400 Series / Portege 3500 Series / 4000 Series / 7000 Series / Tecra 500 Series / 700 Series / R200 / Tecra R10	3	15V
ViewSonic	VB120	5	19V
Gigabyte	T1028G / M912 Series	17	12V

※最新筆電專用對照表請參見本公司網站